


[illegible]

BATTERY SAFETY GUIDELINES:

- 1) You should remove the screw to open the battery cover by using a small cross head screw driver (NOT INCLUDED).
- 2) Install 2 batteries of AA type. Take care to fit the batteries correctly observing the "+" and "-" signs marks on the battery and appliance.
- 3) Batteries should be replaced by an adult.
- 4) Only batteries of the same equivalent type are to be used. Do not mix alkaline, standard (Zinc, carbon), or rechargeable (nickel, cadmium) batteries.
- 5) After batteries are inserted make sure the battery cover is placed back and screwed to secure.
- 6) The supply terminals are not to be short circuited.
- 7) Remove dead batteries and old batteries from toys which are not going to be used for a long time, otherwise the batteries may leak and cause damages.
- 8) Replace the whole set of batteries at one time; do not mix old and new batteries.
- 9) Never dispose batteries in fire as this may cause them to explode.
- 10) Non-rechargeable batteries are not to be recharged.

ΟΔΗΓΙΕΣ ΓΙΑ ΑΣΦΑΛΗ ΧΡΗΣΗ ΤΩΝ ΜΠΑΤΑΡΙΩΝ:

- 1) Για να ανοίξετε το καπάκι της μπαταριοθήκης ξεβιδώστε την βίδα με ένα μικρό καταβίδι (σταυρωτής κεφαλής (δεν συμπεριλαμβάνεται).
- 2) Τοποθετήστε 2 μπαταρίες τύπου AA. Τοποθετείστε τις μπαταρίες μέσα στην μπαταριοθήκη με τη σωστή πολικότητα παρατηρώντας τα σήματα "+" και "-" στις μπαταρίες και τη θήκη.
- 3) Οι μπαταρίες θα πρέπει να αντικαθιστούνται από ενήλικες.
- 4) Μόνο μπαταρίες ισοδύναμου είδους θα πρέπει να χρησιμοποιούνται. Μην συνδυάζετε αλκαλικές, κανονικές (Zink, Carbon) ή επαναφορτιζόμενες (Nickel, Cadmium) μπαταρίες.
- 5) Μετά που θα τοποθετήσετε οι μπαταρίες τοποθετείστε το καπάκι πίσω και βιδώστε τη βίδα για ασφάλεια.
- 6) Τα σιδερικά επαφής δεν πρέπει να βραχυκυκλώνονται.
- 7) Απομακρύνετε τις νεκρές και παλιές μπαταρίες από παιχνίδια που δεν πρόκειται να χρησιμοποιηθούν για μεγάλο διάστημα. Διαφορετικά οι μπαταρίες μπορεί να έχουν διαρροή και να προκαλέσουν ζημίες.
- 8) Αντικαθιστάτε και τις δύο μπαταρίες κάθε φορά. Μην συνδυάζετε παλιές με καινούριες μπαταρίες.
- 9) Ποτέ μην πετάτε τις μπαταρίες σε φωτιά γιατί μπορεί να εκραγούν.
- 10) Μπαταρίες που δεν είναι επαναφορτιζόμενες δεν πρέπει να επαναφορτιζονται.



The image shows the front cover of a booklet titled "mega structures building instructions booklet". The word "mega" is in white lowercase letters on a black rectangular background. The word "structures" is in black lowercase letters on a yellow rectangular background. Below these, the words "building instructions booklet" are written in a yellow, sans-serif font. The background of the entire cover is a photograph of a large, yellow, lattice-like structure, possibly a bridge or a large-scale model, against a blue sky with some clouds.

ferris wheel



building
instructions
booklet



12
ages



models
appropriate
for ages



9+



models to build


1











38

